

DIRECTIONS FOR USING RESURF® VO-50

50/50 (1 TO 1) VERTICAL AND OVERHEAD (VO) EPOXY MORTAR

- “**A**” (EPOXY) SIDE IS **WHITE**
- “**B**” (HARDENER) SIDE IS **BLACK**
- WITH A REASONABLY CLEAN RUBBER GLOVE, PUTTY KNIFE, ETC, SCOOP APPROXIMATELY EQUAL VOLUMES OF “**A**” AND “**B**” (PLACE SIDE BY SIDE TO COMPARE BEFORE MIXING)
- MIX IN A REASONABLY COOL AREA
- MIX UNTIL EVENLY GRAY; NO WHITE OR BLACK SPOTS OR STREAKS
- TROWEL ON (PRESS FIRMLY INTO CONCRETE)
- 2” OR LESS TO FEATHEREDGE PER LAYER (LET SET)
- MIX IN A PINCH OR TWO OF ¼” FIBERGLASS ESPECIALLY WITH THICKER REPAIRS (PROVIDED IN ZIPLOC BAG)

RESURF® VO-50 WILL GET HOT IN MASS. ONCE SPREAD ON, CONCRETE WILL SOAK UP HEAT AND EXTEND WORK TIME CONSIDERABLY. SMALLER BATCHES CAN BE USED MORE QUICKLY AND EXTEND WORK TIME.

SEE VIDEO ON OUR WEBSITE: www.polymerconcreteinc.com

FOR ASSISTANCE PLEASE CALL:

OFFICE: 334-682-4296

HOME: 334-682-4566

CELL: 334-412-2440

CELL: 334-412-1910